



Adapter: connect all vehicles with a single integration


Vehicle API Layer

2hire enables digital services around connected vehicles through a single API platform.

Adapter provides digital access to countless vehicle types, makes and models through standardized and robust APIs.

2hire Box – Not connected vehicles

Though our proprietary hardware, we retrieve vehicle data and trigger remote interactions



Connected vehicles

We partner with manufacturers of connected vehicles in the automotive and micro-mobility world.

With a single layer API, 2hire communicates with connected vehicles of all the major OEMs, creating mobility services with a universal and standardized access point.





Mercedes-Benz



Adapter

Vehicle API Layer



API

Any vehicle, one integration



Build your mobility service in one click




We are your partner, you can count on us!

2hire Box

Integrate not connected vehicles in your fleet through the 2hire Box.


An easy installation (<10 minutes) allows you to send remote commands and to read real time data of the vehicle.



Plug & Play Device (less than 10 minutes to install)



Compatible with all kinds of vehicles



Vehicle interactions and data reading

Interactions



Lock/Unlock Doors



Enable/Disable Immobilizer



Start/Stop
(micro-mobility only)

Data



Odometer



GPS




Fuel/battery level

Connected Vehicles

2hire allows you to integrate connected vehicles in your fleet without the need to install an external device.

We collaborate with the major manufactures to empower innovative mobility services.



Multi-brand compatibility



Remote interactions and data reading

API

Unique integration for any vehicle

2hire

niuv

VAIMOO



SEGWAY

FCA
FIAT CHRYSLER ALLIANCE LTD.

RENAULT

omni

PSA

OKAI

And many more...





Adapter

Vehicle API Layer

Powered by 2hire