

















Wireless data logging at 1 kS/s (1 ms)

330-channel portable logger available with your choice of plug-in modules and wireless modules







Two models: Standard Model and Wireless LAN Model



Standard model (designed for use with plug-in modules only) LR8450

You can add up to 4 plug-in modules which provides 120 channels of measurement






Configuration example: 120 channels of analog input

Plug-in units

VOLTAGE/TEMP UNIT U8552×4

Each VOLTAGE/TEMP UNIT U8552 accepts 30 channels of input. Add four units for 120 channels of measurement.

Depending on various scenes, you can freely combine six types of plug-in modules





Configuration example: 60 channels of analog input + 1,000 channels of CAN input

Plug-in units

VOLTAGE/TEMP UNIT U8552×2 CAN UNIT U8555×2

Each VOLTAGE/TEMP UNIT U8552 accepts 30 channels of input. Each CAN UNIT U8555 accepts 500 channels of input.

Wireless LAN model

Add channels freely via either plug-in or wireless modules

Can also be used exclusively with wireless modules



Wireless LAN model LR8450-01

Add up to 7 wireless modules in total for a maximum of 330 channels

Configuration example: 330 channels

Plug-in modules

VOLTAGE/TEMP UNIT U8552×4



Wireless modules

WIRELESS VOLTAGE/TEMP UNIT LR8532×7



With four U8552 VOLTAGE/TEMP UNITs and seven LR8532 WIRELESS VOLTAGE/TEMP UNITs, you can measure a total of 330 channels.

Mix plug-in and wireless modules

Mixing and matching plug-in modules and wireless modules will allow you to build a measurement system that suits your needs.*1

If wireless modules are used with other modules (wireless or plug-in), the sampling-timing shift between the units is periodically corrected.*2

In addition, at times when the wireless communication is cut off, the correction function works after the communication is restored and the sampling-timing shift between the modules is corrected.

^{*1} Up to four CAN modules can be used at the same time. (Plug-in and wireless modules may be used in any combination.)

^{*2} Even in good wireless communication conditions (low interference) the sampling-timing between modules may shift about 20 ms. In bad wireless conditions, the sampling-timing shift will be much worse than this.

Voltage measurement



Measure outputs from a pressure sensor and other sensors at 1 kS/s max. sampling rate (1 ms interval sampling)

1 kS/s sampling is necessary to record outputs of several tens of Hertz from pressure sensors and vibration sensors.







WIRELESS HIGH SPEED VOLTAGE UNIT LR8533

Temperature measurement





Measure temperature near inverters and batteries at a sampling rate of up to 100 S/s (10 ms interval sampling)




VOLTAGE/TEMP UNIT U8550 UNIVERSAL UNIT U8551 VOLTAGE/TEMP UNIT U8552(*)



WIRELESS VOLTAGE/TEMP UNIT LR8530 WIRELESS UNIVERSAL UNIT LR8531 WIRELESS VOLTAGE/TEMP UNIT LR8532(*)

Consistent sampling rate even with added modules

Each module incorporates its own A/D converter. This design keeps the maximum sampling rate high even when Modules are added.



Example 1: use four U8553 HIGH SPEED VOLTAGE UNITs (with 5 channels each) to measure 20 channels at a sampling rate of 1 kS/s (1 ms).

Example 2: Use four U8550 VOLTAGE/ TEMP UNITs (with 15 channels each) to sample 60 channels at a sampling rate of 100 S/s (10 ms).

Consistent noise resistance even with added modules

Since increasing the number of modules has no effect on the cutoff frequency, which changes with the sampling rate, power supply noise can be reduced without sacrificing noise resistance.

(ex.) Samplr	ng rate: 1 S/s			
Number of channels	Cutoff frequency			
1 ch to 15 ch	60 Hz			
16 ch to 30 ch	60 Hz			
31 ch to 45 ch	60 Hz			
46 ch to 60 ch	60 Hz			
*When using a power supply				
frequency of 60 Hz.	Same cutoff			

Set filters

Set filters for each module



The cutoff frequency, which varies with the data refresh interval, can be set separately for each module. You can use long data refresh intervals, which boost filter effectiveness, and short data refresh intervals for different modules at the same time.

- Measure control signals at maximum speed: module1 (data refresh interval: 1 ms)
- Measure battery voltage fluctuations: module 2 (data refresh interval: 1 ms)
- Measure temperature using thermocouples: module 3 (data refresh interval: 1 s) with strong filter

frequency

^{*}Sampling rate of 100 S/s (10 ms) is available when using 15 or fewer channels.

Strain measurement

Measure strain with a 1 kS/s sampling rate (1 ms)

Connect strain gages directly and measure at a sampling rate of up to 1 kS/s. Strain gages tend to have long, thin wires that are easily broken, but that potential pitfall can be avoided by using wireless modules so that wiring is minimized.






STRAIN UNIT U8554

WIRELESS STRAIN UNIT LR8534


Connect strain gages directly

The strain units have a built-in bridge box, allowing you to connect strain gages directly to their input terminals.



Strain-gage-type converters such as load sensors and pressure sensors can be connected directly to make measurement.







Reduced influence of noise


Stable measurement, even at high voltages and high frequencies

Most competing loggers are incapable of measuring temperature accurately in noisy environments due to the influence of high frequencies, causing values to shift or fluctuate significantly. The LR8450 uses a new design to dramatically reduce the influence of high-frequency noise.

Example: measure temperature by connecting the tip of a K thermocouple to the screw on an inverter's PWM output terminal (W-phase) when using the U8550 VOLTAGE/TEMP UNIT (settings: 10 S/s sampling in the 100°C f.s. range).







Most competing loggers exhibit significant fluctuations when the inverter is operating, whereas the MEMORY HiLOGGER LR8450 does not.


DISTRAME - Tél.: 03 25 71 25 83 - infos@distrame.fr - www.distrame.fr

CAN measurement NEW



One instrument, two uses: **CAN input + CAN output of measured values**

	U8555	LR8535
Input: CAN and CAN FD	Yes	Yes
Output: CAN and CAN FD	Yes	No



Receive CAN signals using a contactless, wireless setup!

Wireless modules interoperate flawlessly with the NON-CONTACT CAN SENSOR SP7001-95! Supply power from the battery-driven wireless unit to the NON-CONTACT CAN SENSOR SP7001-95 via USB to implement a wireless CAN measurement setup that requires no external power supply. (The system can operate for about



five hours on battery power.) Since no ECU analysis tools or computer is required, the setup takes little space to reduce the amount of wiring needed for driving tests.

Convenient function 1 Notification when a specific ID is received

Start and stop measurement when a CAN signal with a specific ID occurs



Convenient function 2 Bit mask trigger function

Set a trigger that corresponds to a particular pattern with the bit mask trigger function. For example, this function can be used when you wish to start recording when a control signal exhibits the specific pattern of "10101010."

Support for multichannel measurement: receive up to 500 channels with 1 module

As a result of electrification, automobiles now use enormous quantities of data internally, and the amount of data on CAN buses consequently is growing. A single CAN module can capture up to 500 channels*1 of data. The LR8450 can accommodate up to four modules, allowing you to measure up to 2000 channels of CAN data. Each channel can collect information for one signal

*1 With a recording interval of 100 ms

Convenient function 3 Sending user-defined CAN frames

Sometimes it's necessary to send a CAN signal to an ECU in advance so that the ECU will output data to the CAN bus. With the U8555, you can send userdefined CAN frames to a CAN bus while performing CAN measurement.

One-time transmission

When you need to send a CAN control frame once in order to change an ECU's operating mode

Repeated transmission


When an ECU won't output the value you wish to capture unless you send specific CAN data each time




CAN UNIT U8555CAN and CAN FD input or output



WIRELESS CAN UNIT LR8535
CAN and CAN FD input only





CAN Editor (standard CAN configuration software accessory)

Install this software from the application disc that comes with the MEMORY HiLOGGER LR8450 onto a PC to easily configure CAN Unit settings.

Setting method Online or offline


Save settings configured using the CAN Editor in the CES format and then load them with the LR8450. You can also configure instruments offline when a LAN or USB connection is difficult to establish.

Receive mode Loading DBC files

In addition to setting up channels manually, you can complete CAN communication definition settings simply by loading a DBC file.

Output mode Automatically configuring output targets

Creating output communication definitions one channel at a time for a logger that's handling a large number of channels is extremely time-consuming. With the CAN Editor, you need only specify the start ID and click the "Configure Automatically" button to complete all communication definitions. Those definitions can then be output as a DBC file and loaded onto an upstream system to complete the configuration process.



Wireless for ease of use

Collect data from dispersed locations all at the same time

The LR8450-01 can simultaneously collect measurement data from wireless units installed on various test equipment.

Collect measurement data from multiple locations with a single logger

Manage data in a single time sequence

Units can be placed in confined locations

Check the display during measurement



Up to 30 m* (line-of-sight)

* Better connection may be attained from placing the LR8450-01 and/or wireless module on the floor or ground for a shorter communication distance.



Peace of mind in the event of an interruption in power or wireless connectivity

Peace of mind if communications are temporarily interrupted

Buffer memory holds up to 5 min.*1 of measurement data

Each wireless unit has a built-in buffer memory that can hold up to 5 min.*1 of measurement data. Data are resent along with more recent measurement data once communications resume, after which the data are restored inside the LR8450-01*2.

The system can be configured to output an alarm if communications are interrupted or if a module encounters a low-battery state.

- *1 The duration for which measurement data can be maintained does not vary with the recording interval (up to a maximum of 5 min.)
- *2 Data collected using the Logger Utility software measurement cannot be restored in this manner.

Battery operation


Use modules in locations where there's no AC power

Example:

The wireless VOLTAGE/TEMP UNIT LR8530 can operate for about 9 hours on battery power. If the unit is charged at night, it can operate on just the battery pack during the day.

Using the Battery Pack Z1007


Wireless module model	Continuous operating time
LR8530	Approx. 9 hr.
LR8531	Approx. 7 hr.
LR8532	Approx. 9 hr.
LR8533	Approx. 9 hr.
LR8534	Approx. 5 hr.
LR8535	Approx. 10 hr.*



Peace of mind in the event of a power outage during measurement

Install a battery pack for peace of mind

If you've installed a battery pack in a module that's being powered by an AC adapter, the unit will automatically switch to battery power in the event of an outage so that the LR8450-01 can continue making measurements.



Make measurements in locations where it would be difficult to route wires

Work time can be reduced using the LR8450-01 and wireless modules, since only minimal wiring is required. If the measurement target is located in a lab, this approach eliminates the need for wiring and avoids having to drill holes in the walls of the monitoring room where data is being checked.

Inside a room, or outside, you can make measurements with the door closed.



Simple registration of wireless modules

Wireless modules, located within the range, that are not connected to another LR8450-01, can be automatically detected. Simply choose the module you wish to register from the list.








Check the unused wireless LAN channels and select the wireless channel to use

You can reduce interference from other wireless devices by using an open channel (wireless frequency range being used by wireless devices in the area). Check for open channels on the instrument's screen.






Observe data from a remote location using a PC or a tablet

By connecting the LR8450-01 to a PC or a tablet via wireless LAN, you can control the instrument remotely using the built-in HTTP server or obtain older data files using the built-in FTP server.

(You cannot use Logger Utility when using Station Mode or Access Point Mode. See below.)

Station mode Connect wirelessly to a third-party access point (AP). STA STA STA STA STA AP DISTRAME - Tél.: 03 25 71 25 83 - infos@distrame.fr - www.distrame.fr

Easy-to-read display of measured values




External control terminals and interfaces to accommodate a broad range of use cases



Motor speed, flow rate integration, etc.


8 channel pulse measurement



In "Revolve" mode, monitor production equipment by measuring the variations in revolution speed of motors or drills. In "Count" mode, identify operation status by acquiring integrated power or flow rate.

Useful in preventive maintenance


8 channel alarm outputs



You can set alarm output for eight channels. You can set a level, a window, a slope, and a logic pattern on channels you wish to monitor.

Two terminals for voltage outputs (5, 12, or 24 V)

Supplying power to the sensors



The LR8450/LR8450-01 provides two output terminals for voltages, each of which can supply 100 mA current, eliminating the need for a separate sensor power supply. You can select 5 V, 12 V, or 24 V from the VOUTPUT1 terminal and 5 V or 12 V from the VOUTPUT2 terminal.

Replace storage media during real-time saving

No need to stop recording

When you remove the storage media while recording data, and reinsert it, data remaining in the internal buffer memory will continue to be stored in a new and different file.



Extensive calculation functions

Numerical calculation function

In addition to the maximum and minimum value calculation functions provided by previous models, the LR8450/LR8450-01 offers an extensive range of calculations, including on/off time, count, and usage ratio.




Types of calculations

Average value
Peak-to-peak value
Maximum value
Minimum value
Time at which maxi- mum value occurred
Time at which mini- mum value occurred
Integration
Aggregation
Usage ratio
On time
Off time
On count
Off count

Waveform calculation function

Calculate data while measurement continues and display calculated waveforms in real time. Calculation results are saved on a separate and dedicated calculation channel.



Types of calculations

Basic arithmetic operations

Aggregation

Simple average

Moving average

Integration

Recording over extended periods of time without interruption

Collect data on a storage device (SD memory card or USB drive) while measuring continues. The ability to segment files by hour or day without stopping measurement is convenient when you need to review data later.



Maximum recording time (estimate)

Example: Recording 30 analog channels with 2 modules (no alarm output or waveform processing)

Because the header portion of waveform files is not included in capacity calculations, expected actual maximum time is about 90% of those in the tables. The maximum recording time varies with the number of measurement channels. Recording times are doubled if the number of measurement channels shown in the table is halved.

When recording 30 analog channels with two U8550/U8551 modules or one U8552 module (no alarm output, no waveform processing) When recording 30 analog channels with two LR8530/LR8531 modules or one LR8532 module (no alarm output, no waveform processing)

Recording intervals	Internal buffer memory (512 MB)	SD MEMORY CARD Z4001 (2 GB)	SD MEMORY CARD Z4003 (8 GB)	USB DRIVE Z4006 (16 GB)
10 ms	1 d	3 d 20 h	15 d 8 h	30 d 12 h
100 ms	10 d 8 h	38 d 18 h	153 d 9 h	305 d 5 h
1s	103 d 13 h	387 d 12 h	1,533 d 21 h	3,052 d 9 h
10s	500 d	3,875 d 6 h	15,339 d 3 h	30,523 d 19 h

When recording 20 channels with four U8553 modules or U8554 modules (no alarm output, no waveform processing) When recording 20 channels with four U8553 modules or LR8534 modules (no alarm output, no waveform processing)

Recording intervals	Internal buffer memory (512 MB)	SD MEMORY CARD Z4001 (2 GB)	SD MEMORY CARD Z4003 (8 GB)	USB DRIVE Z4006 (16 GB)
1 ms	3 h 43 min	13 h 56 min	2 d 7 h	4 d 13 h
10 ms	1 d 13 h	5 d 19 h	23 d	45 d 18 h
100 ms	15 d 12 h	58 d 3 h	230 d 2 h	457 d 20 h
1s	155 d 8 h	581 d 7 h	2,300 d 21 h	4,578 d 13 h
10s	500 d	5,813 d 1 h	23,008 d 20 h	45,785 d 20 h

When recording 330 channels with four U8552 modules and seven LR8532 modules (no alarm output, no waveform processing)

Recording intervals	Internal buffer memory (512 MB)	SD MEMORY CARD Z4001 (2 GB)	SD MEMORY CARD Z4003 (8 GB)	USB DRIVE Z4006 (16 GB)
20 ms	4 h 8 min	15 h 28 min	2 d 13 h	5 d 2 h
100 ms	20 h 42 min	3 d 5 h	12 d 18 h	25 d 10 h
1s	8 d 15 h	32 d 6 h	127 d 19 h	254 d 8 h
10s	86 d DIST	RAMÊ ² -⁴Tél ⁶ :¹03 25 71 2	5 83๋ ^{,2} 7ักfซิร@ิฮีเริtrame.fr -	www ² :āfstrame ⁹ fr ^h

Control the instrument remotely and capture data on a PC


HTTP server function

Control the instrument remotely from a PC

Use a standard Web browser to control the LR8450/LR8450-01, start and stop measurement, then enter comments.

Use a mouse to operate waveforms displayed on a PC

Enjoy intuitive mouse-based control, including waveform scrolling and cursor operations.



FTP server function

Download data files onto a PC

Your PC can get files from inside the SD memory card or USB drive inserted to the LR8450/LR8450-01.

FTP client

Automatically transfer data files to an FTP server

Automatically transmit files to an FTP server from the SD memory card or in the USB drive inserted to the LR8450/LR8450-01.

NTP client function

Set the logger's clock

Set the clock in the LR8450/LR8450-01 and synchronize it to an NTP server on the network.

E-mail transmission function

Receive email notices on errors and other information

Receive emails to your PC or mobile phone when there is a communication loss and when an error occurs during measurement and wireless module communications.

It can also send instantaneous values by e-mail periodically.

Use with other tools



Output measured values using XCP on Ethernet

The LR8450 supports XCP slave operation based on the XCP protocol, a standard developed by the Association for Standardisation of Automation and Measuring Systems (ASAM). You can perform control to start and stop measurement and acquire measured values using an XCP master. (Measured values from CAN modules cannot be output.)





CAN-FD – Powertrain

CAN-FD – ADAS

CAN – Body

Vehicle bus

ECU access

ECU RAM measurement and calibration task

CAN bus measurement

GateWay ECU

ECU/bus measurement interface

- •Overwrite control parameters while ECUs continue to operate
- Consolidate data from multiple measurement systems and buses
 Monitor large amounts of microcontroller RAM at high speeds

NEW

Load data using MDF-compatible waveform viewers

Voltage, temperature, strain, CAN, and other measurement data captured by the LR8450 can be saved in the Measurement Data Format (MDF) and loaded by other software that supports the format.

Commercially available software

FAMOS

- · More than 400 calculation processing variables
- · Easy report creation functionality


FlexPro



- · High-speed search and processing of large volumes of data
- Share analysis templates within your company


DISTRAME - Tél. : 03 25 71 25 83 - infos@distrame.fr - www.distrame.fr

NI DIAdem



- Functionality ranging from searching and loading of data to analyzing and creating of reports
- · Dialog-based interface

OS-2000



- Freely edit large data that cannot be handled by Excel
- Simultaneously display the waveforms which have different frequencies

Logger Utility (standard accessory)

Collect data at sampling speeds of up to 10 ms on a PC



ity application software, a standard accessory. You can even scroll waveforms backwards to view older data while recording is in progress. A real-time measurement is supported for recording intervals of 10 ms or longer.

Record data on a PC in real time using the Logger Util-

U8555 and LR8535 CAN Unit real-time measurement and viewing of waveform data are not supported. Please use the GENNECT One software for real time viewing of CAN data by the U8555 and LR8535.

Recording No. of connected Simultaneous recording interval units destination 2035 channels PC 10 ms up to 5

calculation channels

+ 60 waveform



Simultaneously log data from five LR8450 instruments at a speed of up to 10 ms.

Connection

method


LAN/USB



Display logged data in real time as a graph.

GENNECT One

Make simultaneous measurements using multiple instruments



Aggregate measurement data from not only loggers, but also waveform recorders, power meters, and other instruments onto a single PC.

Display this measurement data on a single graph in real time. Summarize it in daily and monthly reports. Manage in in a centralized manner. GENNECT One is a Windows application that specializes in aggregating measurement data.

Data including CAN data from the U8555 and LR8535 can be viewed and measured in real time (logging function, dashboard function). Real time measurement and viewing of CAN data will be available from the LR8450's next firmware update around mid or late 2022.

> GENNEC One is a free application. Access this 2D Code for details and downloads.



Recording interval 1 s

Simultaneous recording

Total No. of connected devices

Save destination Connection method

512 channels

up to 15*

PC

LAN

*Up to 30 devices can be connected when using only the logging or dashboard functions



Simultaneously log data from instruments like recorders and power meters as frequently as 1 s.



Display logged data in real time as a graph. Automatically create CSV files and daily/monthly reports.



Graphically display measured values using the dashboard function. Visually identify anomalies.



Download instrument data files saved on instruments' SD cards.



Change instrument settings remotely.

Specifications

Specific	catio	ns						
			ry HiLogger	LAN interface			s and controlling recording using communica-	
Product warran			sic specifications				data using the FTP server: Acquiring files fron emory Card or USB Drive	
Accuracy guarar		1 year				Automatically send	ing of data via FTP (FTP client)	
Maximum numl			n modules + 7 wireless modules* *LR8450-01 only than 4 CAN modules (U8555 and/or LR8535) can be connected.			Waveform files whil	ved on a connected SD Memory Card or USB Dri e measurement is in progress: binary, text, MDF	
Connectable i (plug-in mod	modules	U8550 U8551	VOLTAGE/TEMP UNIT U8553 HIGH SPEED VOLTAGE UNIT UNIVERSAL UNIT U8554 STRAIN UNIT VOLTAGE/TEMP UNIT U8555 CAN UNIT		Waveform files after measurement has finished: binary, text, numerical calculation result files HTTP server function			
Connectable	modules) WIRELESS VOLTAGE/TEMP UNIT				and remotely controlling instrument and	
(wireless mo (LR8450-01	odules)	LR8532 LR8533 LR8534	I WIRELESS UNIVERSAL UNIT 2 WIRELESS VOLTAGE/TEMP UNIT B WIRELESS HIGH SPEED VOLTAGE UNIT 4 WIRELESS STRAIN UNIT			surement, acquiring instrument and mode (up Browsing mode (up	measured value display, starting/stopping mea og data via FTP, setting comments, updating odules o to four instruments): , measurement status, and comments	
Internal buffer	memory		5 WIRELESS CAN UNIT memory, 256 M-words			Email transmission		
Clock functi			alendar, automatic leap year recognition, 24-hour clock			Start trigger, stop tri	gger, alarm, power outage recovery, internal buff full, wireless unit communication interruption, bat	
Clock precise (precision of cloth played by instrument as start/sto	ock dis- ument as	Time ca	day (at 23°C) an be synchronized with an NTP server to which the instruconnected.			attached for start trig Emails can be sent	ic mail transmission. Instantaneous values can b gger, stop trigger, alarm, and periodic transmission t regularly at the following intervals: 30 min., 1	
		±0.2 s/c	day (at 23°C)			12 h, or 1 day. NTP client function		
Backup batt service life	tery	For clo	ck, at least 10 years (reference value at 23°C)			Regular synchroniz	on with an NTP server zation intervals: 1 h, 1 day synchronization function	
			s, pollution degree 2, altitude up to 2000 m	Wireless		02.11b/g/n	•	
Operating tem and humidity r			to 50°C (14°F to 122°F), 80% RH or less (non-condensing) ng temperature range: 5°C to 35°C)	LAN interface	Encryp		, line of signt K/WPA2-PSK, TKIP/AES	
Storage temp and humidity	range		to 60°C (-4°F to 140°F), 80% RH or less (non-condensing)	(LR8450-0 only)	Auto-co Suppor	ted modes: access poi	s LAN function can be toggled on and off. nt, station, wireless module connectivity	
Dimensions		Without any modules: 272W × 145H × 43D mm (10.72"W × 5.71"H × 1.69"D) (excluding protrusions) With 2 modules: 272W × 198H × 63D mm (10.71"W × 7.8"H × 2.78"D)			Devices that can be connected in wireless module connectivity mode: wire modules or PC/tablet You can use either a wireless module or PC/tablet with wireless connection			
		With 4 i	ing protrusions) modules: 272W × 252H × 63D mm (10.71″W × 9.92″H ×			ss Configuring setting nc- communications co	s and controlling recording using	
Moss			(excluding protruding parts)		tionality		data using the FTP server	
Mass Standards			. 1108 g (39.08 oz.) (excluding battery pack) EN61010				a a connected SD Memory Card or USB Drive	
		EMC: E	N61326 Class A				ing data via FTP (FTP client) ved on a connected SD Memory Card or USB Dri	
Vibration resistance			601:1995:1995 5.3 (1) : Passenger vehicles; conditions: Class A equivalent			HTTP server functi Control mode (one		
Accessories	Cocessories Quick start manual, LOGGER application disc (quick start minstruction manual, logger utility, logger utility instruction manual, cAN editor, CAN editor instruction manual, communication in		ion manual, logger utility, logger utility instruction manual, ditor, CAN editor instruction manual, communication instruc- nual), USB cable, AC adapter Z1014, precautions concerning			Displaying screen ules, current meas	and remotely controlling instrument and mod sured value display, starting/stopping measure ata via FTP, configuring comment, updating th	
		use of e	equipment that emits radio waves (LR8450-01 only)				to four instruments):	
Display						Displaying screen status, and comm	, current measured value display, measureme ents	
Display		7-inch	TFT color LCD (WVGA 800 × 480 dots)			Email transmission		
Display reso (with wavefo display sele	orm		0 divisions (horizontal axis) × 10 divisions (vertical axis) ion = 36 dots [horizontal axis] × 36 dots [vertical axis])			memory full, media for tery, and periodic ma	ger, alarm, power outage recovery, internal buffer, ill, wireless unit communication interruption, low ba il transmission. Instantaneous values can be attact trigger, alarm, and periodic transmission.	
			se, English, Chinese, Korean			Emails can be sent reg	gularly at the following intervals: 30 min, 1 h, 12 h, 1 da	
Backlight sen Backlight sa			. 100,000 h (reference value at 23°C) ff backlight when no key is operated for a set amount of time			NTP client function Time synchronizati	on with an NTP server	
Backlight brig			s (user-selectable)			Regular synchroniz	zation intervals: 1 h, 1 day	
Waveform		Dark/lig	Dark/light (user-selectable)		Pre-measurement synchronization function Standard compliance: USB 2.0 compliant			
background	COIOF			USB interface	Conne	ctors: Series A receptad	cle × 2	
Power sup	pply			(host)		nteed-operation options stem: FAT16, FAT32	: Z4006 USB drive (16 GB)	
Power supply	AC ad	apter	Z1014 AC Adapter (12 V DC ±10%) AC Adapter rated supply voltage: 100 V to 240 V AC (as-		Connec	ctable devices: keyboar	rd, mouse, hub (1 layer), USB drive (1 port onl	
oupp.)			suming voltage fluctuation of ±10%) AC Adapter rated power supply frequency: 50/60 Hz	USB interface		USB standard: USB 2.0 compliant Connector: series mini-B receptacle		
	Battery	/	LR8450 accommodates 2 batteries	(function	10011110	inctionality: data acqui	sition, condition settings used with the Logge	
			Z1007 Battery pack (when used with AC Adapter, AC Adapter takes priority)			Configurin	ware (bundled) g settings and controlling recording using co	
			Li-ion, 7.2 V, 2170 mAh		LISB dri		ns commands ta from a connected SD memory card to a comput	
	Extern	al supply	10 V to 30 V DC	SD card		rd compliance: SD star	ndard-compliant slot × 1 (with SD memory card	
Power consumption	Norma	I power mption	Using Z1014 AC adapter or 12 V DC external power supply, without Battery Pack With LCD at maximum brightness: 8.5 VA (instrument only)	slot			memory card support) : Z4001 (2 GB), Z4003 (8 GB)	
			With LCD backlight off: 7 VA (instrument only)	E .				
	Maxim rated p		When using the Z1014 AC adapter 95 VA (including AC adapter)		l control t		minal black	
			When using a 30 V DC external power supply 28 VA (while charging battery with LCD at maximum brightness)	Terminal External	1	Push-button type terr of 4, non-isolated (same		
			When using the Z1007 Battery pack	I/O	terminals	,	,	
Continuous	Batter	/	20 VA (with LCD at maximum brightness) With one Z1007 Battery pack: approx. 2 h (reference value at 23°C)		Input	Input voltage Slope	0 V to 10 V DC Rising/falling (user-selectable)	
operating time	Battory	,	With two Z1007 Battery packs: approx. 4 h (reference value at 23°C) Conditions: with one U8551 Universal Unit connected, backlight on, voltage output off, and Z4006 con-			Functionality	Choose from off, start, stop, start/stop, trigge input, event input	
			nected		Output	Output format	Open-drain output (with 5 V voltage output)	
Charging functionality	AC ad	apter is	ailable when the Z1007 Battery pack is attached and the connected.			Maximum switching capacity	5 V to 10 V DC, 200 mA	
<u> </u>		ing time:	Approx. 7 h (reference value at 23°C)			Functionality	Trigger output	
Interface s				Alarm ou	utput	Output format	Open-drain output (with 5 V voltage output)	
			B interface (function) cannot be used at the same time			Maximum switching capacity	,	
interface /	Auto MD	I-X, DH	ernet, automatic 100Base-TX/1000Base-T detection CP, DNS supported	Voltage	outnut	Output voltage	8, non-isolated (same GND as instrument) Off, 5 V, 12 V, 24 V* (user-selectable)	
1		n cable	5 length: 100 m /: Acquiring data and setting recording conditions with Logger	90	T- 2.	, , , , , , , ,	Supply current: max. 100 mA each *24 V output can be selected for the VOUT- PUT1 terminal only	

GA 800 × 480 dots)			Email transmission				
al axis) × 10 divisions (vertical axis) ontal axis] × 36 dots [vertical axis])			memory full, media fu tery, and periodic ma	o trigger, alarm, power outage recovery, internal buffer, ia full, wireless unit communication interruption, low bat- c mail transmission. Instantaneous values can be attache stop trigger, alarm, and periodic transmission.			
e, Korean				ularly at the following intervals: 30 min, 1 h, 12 h, 1 day.			
ice value at 23°C)	NTP client function						
key is operated for a set amount of time			Time synchronization	on with an NTP server			
.,			Regular synchroniz	ation intervals: 1 h, 1 day			
			Pre-measurement :	synchronization function			
	USB	Standard	d compliance: USB 2.0) compliant			
	interface		Connectors: Series A receptacle × 2				
	(host)		, ,	: Z4006 USB drive (16 GB)			
(12 V DC ±10%)		,	em: FAT16, FAT32				
supply voltage: 100 V to 240 V AC (as-	1100			d, mouse, hub (1 layer), USB drive (1 port only)			
ctuation of ±10%)	USB interface		ndard: USB 2.0 comp				
power supply frequency: 50/60 Hz	(function		or: series mini-B rece				
dates 2 batteries	(USB fun	Utility softy	sition, condition settings used with the Logger vare (bundled)			
c C Adapter, AC Adapter takes priority) mAh			Configuring munication	g settings and controlling recording using com- s commands			
				a from a connected SD memory card to a computer			
	SD card	Standard		dard-compliant slot × 1 (with SD memory card/			
dapter or 12 V DC external power sup-	SIOT	Guarant	SDHC memory card support) eed-operation options: Z4001 (2 GB), Z4003 (8 GB)				
Pack			em: FAT16, FAT32	. 24001 (2 GB), 24003 (8 GB)			
num brightness: 8.5 VA (instrument only) t off: 7 VA (instrument only)		I lie syst	ciii. 1 Al 10, 1 Al 02				
014 AC adapter	External	control te	rminals				
C adapter)	Terminal			ningl block			
DC external power supply			push-button type terminal block mber of 4, non-isolated (same GND as instrument)				
ng battery with LCD at maximum brightness)	I/O	terminals	4, non-isolateu (same	e GND as instrument)			
maximum brightness)	1,0	Input	Input voltage	0 V to 10 V DC			
ry pack: approx. 2 h (reference value at 23°C)		iiiput	Slope	Rising/falling (user-selectable)			
v packs: approx. 4 h (reference value at 23°C)			<u>'</u>	0 01			
e U8551 Universal Unit connected,			Functionality	Choose from off, start, stop, start/stop, trigger			
				input event input			
		Output	Output format	Open-drain output (with 5 V voltage output)			
ht on, voltage output off, and Z4006 con-		Output	Output format	Open-drain output (with 5 V voltage output)			
nt on, voltage output off, and Z4006 con-		Output	Maximum switching capacity	Open-drain output (with 5 V voltage output) 5 V to 10 V DC, 200 mA			
ht on, voltage output off, and Z4006 con- 007 Battery pack is attached and the		Output	Maximum switching	Open-drain output (with 5 V voltage output) 5 V to 10 V DC, 200 mA Trigger output			
ht on, voltage output off, and Z4006 con- 007 Battery pack is attached and the	Alarm ou	·	Maximum switching capacity	Open-drain output (with 5 V voltage output) 5 V to 10 V DC, 200 mA			
ht on, voltage output off, and Z4006 con- 007 Battery pack is attached and the nce value at 23°C)	Alarm ou	·	Maximum switching capacity Functionality Output format	Open-drain output (with 5 V voltage output) 5 V to 10 V DC, 200 mA Trigger output			
007 Battery pack is attached and the nce value at 23°C) on) cannot be used at the same time	Alarm ou	·	Maximum switching capacity Functionality Output format Maximum switching capacity	Open-drain output (with 5 V voltage output) 5 V to 10 V DC, 200 mA Trigger output Open-drain output (with 5 V voltage output)			
on) cannot be used at the same time Base-TX/1000Base-T detection	Alarm ou	utput	Maximum switching capacity Functionality Output format Maximum switching capacity	Open-drain output (with 5 V voltage output) 5 V to 10 V DC, 200 mA Trigger output Open-drain output (with 5 V voltage output) 5 V to 30 V DC, 200 mA 8, non-isolated (same GND as instrument) Off, 5 V, 12 V, 24 V* (user-selectable) Supply current: max. 100 mA each *24 V output can be selected for the VOUT-			
ht on, voltage output off, and Z4006 con- 007 Battery pack is attached and the nce value at 23°C) on) cannot be used at the same time Base-TX/1000Base-T detection setting recording conditions with Logger	Voltage o	output	Maximum switching capacity Functionality Output format Maximum switching capacity Number of terminals Output voltage	Open-drain output (with 5 V voltage output) 5 V to 10 V DC, 200 mA Trigger output Open-drain output (with 5 V voltage output) 5 V to 30 V DC, 200 mA 8, non-isolated (same GND as instrument) Off, 5 V, 12 V, 24 V* (user-selectable) Supply current: max. 100 mA each "24 V output can be selected for the VOUT-PUT1 terminal only			
ht on, voltage output off, and Z4006 con- 007 Battery pack is attached and the nce value at 23°C) on) cannot be used at the same time Base-TX/1000Base-T detection setting recording conditions with Logger	Voltage o	output	Maximum switching capacity Functionality Output format Maximum switching capacity Number of terminals Output voltage	Open-drain output (with 5 V voltage output) 5 V to 10 V DC, 200 mA Trigger output Open-drain output (with 5 V voltage output) 5 V to 30 V DC, 200 mA 8, non-isolated (same GND as instrument) Off, 5 V, 12 V, 24 V* (user-selectable) Supply current: max. 100 mA each *24 V output can be selected for the VOUT-PUT1 terminal only 2, pn-isolated (same GND as instrument)			

LAN functionality: Acquiring data and setting recording conditions with Logger Utility

Recording				Loading		0	20 10 1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
Recording ma		mal s* 2	ms*, 5 ms*, 10 ms, 20 ms, 50 ms, 100 ms, 200 ms, 500 ms, 1 s,	Loading data	saved		position and then loads up to 256 mega-data-points of aved text-format data.
Recording in	s, 5	s, 10	s, 20 s, 30 s, 1 min., 2 min., 5 min., 10 min., 20 min., 30 min., 1 l	1		· · · · · · · · · · · · · · · · · ·	
ata rofrash i			railable only when using a module with data refresh intervals that include 1 ms	Calcula			
Repeat recor			ically- or user-selected value per module ser-selectable)	_ Numerica calcula-	Number of calculations	Up to 10 calc	ulations simultaneously
Specified ime/continuo	Special Specia	ecified ne car al 250 ntinuo naxim	time: recording time is set in days, hours, minutes, and seconds in be set up to maximum capacity of internal buffer memory. If mega-data-points is performed once until it is stopped. If the capacity of internal buffer memory is exceeded, memory verwritten.		Calculation content	time, minimur usage ratio*², *1: total, posi *2: threshold	e, peak-to-peak value, maximum value, maximum value n value, minimum value time, integration*1, aggregation* on time*2, off time*2, on count*2, off count*2 tive, negative, or absolute value (user-selectable) values can be set for individual channels
Vaveform ecording	form Last 256 mega-data-points are saved in internal buffer memory.		_	Calculation range	calculations After recordin calculations p	performed for all data during recording g has stopped: performed for all data in the internal buffer memory, or for da	
ackup of record	led data Noi	ne		_	Time split		on range specified by the A/B cursors (on the vertical axis) abled, or timed (user-selectable)
Display					calcula-	Disabled: cald	culations performed for all data during recording
Sheet functio	Ma CA cha	x. nur N cha innels	neets can be switched between all channels and individual modules mber of channels on all-channel display sheet: 120 analog/annels, 30 waveform calculation channels, 8 pulse/logic s, 8 alarm channels		tion	sure Segmentatio Timed: calcula on the previou Reference til	a for each segment of time, starting with the start of mea ment in time: set DD:HH:MM format ations will be made at intervals of the segment time bas usly set reference time. me: set in hours and minutes.
Vaveform dis creen	(cha Sim valu	annel : ultane ies, cu	waveform display: simultaneous display of gages and settings settings and display settings) sous display of time-axis waveforms and values: instantaneous proor values, or numerical calculation values (user-switchable)	Waveform calculations	Calculation	Arithmetic op	min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, h h, 4 h, 6 h, 8 h, 12 h, 1 d rerations among channels e, simple average, aggregation, and integration of any channel
Display forma	cal Alai	values m dis	I display: simultaneous display of instantaneous values and statisti- splay: display of alarm status and alarm history s waveform display: 1 screen			Calculated va through W30)	alues are recorded as data for calculation channels (N . (Calculations are performed at the same time as measu cannot be recalculated after measurement.)
John William			eform display: 1 screen	Trigger	s		
(-Y composit			ite up to 8 waveforms.	Trigger n		Digital comp	arison method
lumerical dis ormat			decimal, or exponent (user-selectable) ecimal is selected, number of decimal places to display can	Trigger ti	ming	Start, stop, o	or start & stop
Vaveform co	lors 24	set (v colors	alues will then be rounded to set number of places).	Trigger c	Trigger conditions		eration performed on trigger source, interval trigger, or ger 's are disabled, free run
coming in a ut on the	axis		2 ms to 1 day/division	Trigger s		Analog, puls	e, logic, waveform calculations, CAN (max. 100) Level triggers: trigger activated by arising or falling
waveform display	ipiay Verti axis	ertical Number of divisions per screen: 10 Setting method Select position or upper and lower limits for each channel. (Waveform calculation channels: upper and lower limits only)		mgger g	Trigger types		edge at a set level Window triggers: it is set by trigger level upper limit and lower limit. Trigger activated when value leave:
			When setting by position: set zoom factor and zero position. Zoom factor: 1/2 ×, 1 ×, 2 ×, 5 ×, 10 ×, 20 ×, 50 ×, 100 × Zero position: −50% to 150% (with a zoom factor of 1 ×)				area or when value enters area Trigger activated when patterns of 1/0/X match (wh "X" indicates either)
	II' D'.		When setting by upper/lower limit: set upper and lower limit.		Interval triggers		ated for set recording interval after setting days/hours
Vaveform sc	rolling Dis rec	play o ording	can be scrolled left and right both during recording and while g is stopped (during waveform rendering only)	External	triagers	minutes/seco	ated by rising or falling edge at set level in external in
	mer e status Ind	mory (icates	stantaneous values and waveforms without recording data to values and waveforms can be displayed while waiting for a trigger s the battery remaining and the radio-wave strength, in the ls, of the wirelessly connected modules			signal. Rising	g/falling (user-selectable) plug-in units: rval or data refresh interval, whichever is longer)×2+1ms+an:
ispiay (LIN0450-	or only) Tou	i ieve	is, of the whelessly connected modules			When using v	vireless units (LR8450-01 only):
Save lestinations file names	(only stora	age m	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters	-		response time *1: depends of 5 ms and	erval or data refresh time, whichever is longer)×2+wirele s*²+ analog response time*¹ on filter settings (U8554 with a data refresh interval of low-pass filter of 120 Hz). radio-wave state is in good condition, 1s.
uto saving	Automatic	num	bering, dating, assignment of title comment (user-selectable real-time saving): off, binary format, text format, or MDF format		Trigger level resolution		0.1% f.s. (f.s. = 10 divisions) Count = 1c, rotational speed = $1/n$ (where n = pulse)
g	(user-select Numerical of When text	table) calcula form	ation results (saved after recording): off or text format (user-selectable at is selected, choose whether to save all calculations in one		Pre-triggers Set day/hours/minutes/seconds. Can be set during real-time saving.		
	file or to s Delete an		ach calculation in its own file. On/off (user-selectable)	Alarms			
	save		Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.	Alarm co		Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are: • AND/OR operation performed on alarm sources • Low battery • Thermocouple burnout	
			No segmentation, 1 day, 1 week, or 1 month (user-selectable	,		Wireless er	ror (LR8450-01 only)
F	File splitting		plitting Disabled, enabled, or timed (user-selectable) Disabled: data for each recording session is saved in its own file. Enabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment			Alarm output module is de Off/now/3 mi Now: outputs	e, logic, waveform calculations, CAN (max. 100) t when a wireless communication error with a wireless tected n (user-selectable) s an alarm upon a communications disruption ts an alarm if a communication disruption continues for
			time based on the previously set reference time and saved in separate files. Reference time: set in hours and minutes.	Low rem	fe	Alarm output instrument o	when low remaining battery life is detected for the r a wireless module.
	External media eject (SD memory card or USB drive) Data protec- tion		Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d	Thermoo burnout	ouple		when a thermocouple burnout occurs (when Tc burnoung is enabled)
			al media External media can be ejected during real-time saving by D memory activating a button on the screen and confirming a message.	Types of	alarms	Analog, pulse, waveform calculation,	Level: system will output an alarm following a rising falling edge at set level Window: set upper limit and lower limit
						CAN	System will output an alarm when value leaves area when value enters area Slope: set level and time. The system will output an alarm when the rate of
	surement operation will continue). Data is saved when SAVE key is pressed. Choose either selective save or immediate save as an operation to perform when SAVE key is pressed.				Logic	change (level per unit time) continues to exceed the specified change rate during the set time interval. System will output an alarm when patterns of 1/0/X	
Manual saving Decimation			Off, or a value from 1/2 to 1/100,000 (user-selectable)	-			match (where "X" indicates either)

Alarm retention	On/off (user-selectable) Clear alarms: when alarm retention is on, alarms will be cleared without stopping recording.
Alarm tone	On/off (user-selectable)
Alarm output response time	When using plug-in units: (recording interval or data refresh interval, whichever is longer) × 2+1 ms+analog response time*1 When using wireless units (LR8450-01 only): (recording interval or data refresh interval, whichever is longer) × 2+wireless response time*2+ analog response time*1 *1: depending on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz). *2: when the radio-wave state is in good condition, 1s.

Other functions	ality					
Even mark function	Number of inputs	Up to 1000 inputs per measurement				
Waveform search	Search waveform	Search waveforms and display target location in center of waveform screen.				
function	Search conditions Search by choosing level, window, maximum value, minimum value, local maximum value, or local minimum value.					
	Search range	All data in internal buffer memory or data between A/B cursors (on vertical axis)				
	Search targets	Analog, pulse, logic, waveform calculations				
Jump function	Specify event modisplay position	nark, A/B cursor position, trigger point, or waveform to display that section in center of waveform screen.				
Cursor	Cursor display	All channels or specified channels (user-selectable)				
measurement function	Cursor movement	A, B, or simultaneous (user-selectable)				
Turicuori	Types of cursors	Vertical or horizontal (user-selectable)				
Scaling function	Scaling settings	s can be configured separately for each channel				
Comment entry function	Enter titles and	channel-specific comments				
Start state retention function	On/off (user-se	lectable)				
Auto-start function	On/off (user-se	lectable)				
Functionality for saving setting conditions	Up to five groups of setting conditions can be saved in the instrument's internal backup memory.					
Auto setup function	Setting conditions saved in the instrument's memory or on an SD memory card or a USB drive can be automatically loaded when the instrument is powered on.					
	If there are setting conditions stored in the instrument's memory as well as on an SD memory card and a USB drive, setting conditions have the following precedence:					
	instrument's memory, SD memory card, and USB drive.					
Prevention of inadvertent START/ STOP key operation	When START or STOP key is pressed, system will display a message asking if user wishes to start or stop measurement. Confirmation message: enable/disable (user-selectable)					
Key lock function	Disables operation keys					
Beep tone	On/off (user-selectable)					
Self-check function	Can check keys, LCD, ROM/RAM, LAN, media, and modules.					
Display of horizontal axis (time values)						
Measurement start/ stop time specifica- tion function	1	ent start and stop conditions. set start time and stop time (year, month, day, hour, and				
Configuration navigation (quick set) function	nectivity trouble display (strain o	le registration guide (LR8450-01 only), wireless con- eshooting guide (LR8450-01 only), connection diagram gage, external terminals), loading setting conditions				
Power supply frequency filter function	50/60 Hz select	tion				

lr	Input				
Р	ulse/logic input				
Number of channels (common GND, non-isolated) Exclusive setting for pulse/logic input for individual characteristics.		8 channels (common GND, non-isolated) Exclusive setting for pulse/logic input for individual channels			
	Terminal block	Push-button type terminal block			
	Adaptive input format	Non-voltage contact, open collector (PNP open collector requires external resistor), or voltage input			
	Maximum input voltage	0 V to 42 V DC			
	Input resistance	1.1 MΩ ±5%			
	Detection level	2 levels (user-selectable) High: 1.0 V or greater; low: 0 to 0.5 V High: 4.0 V or greater; low: 0 to 1.5 V			

Pulse input

Measurement range, resolution

mada and an					
	Measurement target Count Rotational speed		Range	Maximum resolution	Measurable range
			1000 mega-pulse f.s.	1 pulse	0 to 1000 M pulse
			5000/n (r/s) f.s.	1/n (r/s)	0 to 5000/n (r/s)
			300,000/n (r/min) f.s.	1/n (r/min)	0 to 300,000/n (r/min)
			n: number of pulses per rotation (1 to 1000)		
			ter off: 200 µs or greater (100 µs or greater during high and low interval) ter on: 100 ms or greater (50 ms or greater during high and low interval)		
Slope		Set rising/falling for each channel.			
Measurement mode		Integration (addition, instantaneous), rotational speed			
Integration		Addition: counts number of pulses input from start of measurement. Instantaneous: counts number of pulses input within each recording interval (integrated value is reset for each rotational interval).			
	otational eed	r/s: counts number of input pulses during 1 s and calculates rotational speed. r/min: counts number of input pulses during 1 min and calculates rotational speed.			
Smoothing Select		Select v	ralue from 1 s to 60 s (valid only when set t	o rotational speed

Chatter pre- vention filter	Set to on/off for each channel
Logic input	
Measure- ment mode	Records 1 or 0 for each recording interval

Software Logger Utility specifications

U8555 CAN unit and	LR8535 wireless CAN unit are not supported.
Operating Environment	Windows7 (32/64 bit) Windows8 (32/64 bit) Windows10 (32/64 bit)
Overview	Control PC-connected logger to receive, display, and save measured waveform data sequentially. (Total recording samples is maximum 10 million data. Data exceeding this number will be segmented into separate measurement files while recording continues.) *Real-time measurement on the LR8450, LR8450-01 is possible with a recording interval of 10 ms or more.
Function	Controllable loggers: 5 Data Collection System: 1 system Display Format: • Waveforms (split time-axis display is possible) • Numerical values (logging): numerical display can be enlarged • Alarms Above items can be displayed simultaneously Numerical value monitor Display: display in a separate window is possible. Scroll: waveforms can be scrolled during measurement.
Data Collection	Settings: data collection settings of logger modlues can be configured Monitor function can be checked before measurement. Save: save settings from multiple devices supporting real-time measurement (LUS format) and measurement data (LUW format) as one file. Data save format: real-time data collection file (LUW format), transfer data in real-time or non-real-time to Microsoft Excel®, Excel® template can be specified Event mark: recording during measurement is possible
Waveform Display	Supported files: waveform data file (LUW format, MEM format) Display format: waveforms (split time-axis display available), simulta- neous display of numerical values (logging) is available Maximum number of channels: 2,035 channels (measured) + 60 channels (waveform calculation) Waveform display sheets: waveform of each channel can be dis- played on any of the ten sheets Scroll: available Event mark recording: available Cursors: cursors A and B can be used to display voltage values at cursor positions. Screen capture: screen capture of waveform display is available
Data Conversion	Applicable files: waveform data file (LUW format, MEM format) Conversion section: all data, specified section Conversion format: CSV format (comma delimited, space delimited, tab delimited), transfer to Excel® sheet, LR5000 format (hrp2,hrp) Data thinning: simple thinning with any thinning number
Waveform Calculation	Calculation items: arithmetic operations Number of calculation channel: 60 channels
Numerical Calculations	Applicable data: waveform data file (LUW format, MEM format), real- time measurement data, waveform calculation Calculation items: average value, peak value, maximum value, time to maximum value, minimum value, time to minimum value, on time, off time, on count, off count, standard deviation, aggregation, area value, and integration Save calculation: performs numerical calculation and save to file
Search	Applicable data: real-time data collection file (LUW format), main unit measurement file (MEM format), waveform calculation data Search mode: event mark, date and time, maximum position, minimum position, local maximum position, local maximum position, level, window, and variation
Print	Applicable printer: printer compatible to the OS in use Applicable data: waveform data file (LUW format, MEM format) Print format: waveform image, report print, list print (channel settings, event, cursor value) Print area: all area, specified area by A-B cursor Print preview: available

Option specifications (sold separately)

${\bf Plug\text{-}in\ units:\ U8550,\ U8551,\ U8552,\ U8553,\ U8554,\ U8555}\\ {\bf Shared\ specifications}$

Host model	LR8450/LR8450-01 MEMORY HILOGGER
Operating temperature and humidity range	-10°C to 50°C, 80% RH or less (non-condensing)
Storage temperature and humidity range	-20°C to 60°C, 80% RH or less (non-condensing)
Vibration resistance	JIS D 1601:1995 5.3 (1), Class 1A (passenger vehicle) equivalent
Accessories	User manual, mounting screw × 2, wiring confirmation label (U8554 only)

Wireless units: LR8530, LR8531, LR8532, LR8533, LR8534, LR8535 Shared specifications

Host model	LR8450-01 MEMORY HILOGGER		
Control communications method	Connect wirelessly via Z3230 WIRELESS LAN ADAPTER (included)		
Communications buffer memory	4 Mword (volatile memory) Saves data in the event of a communications error. Data is resent when communications are restored.		
Operating temperature and humidity range	-20°C to 55°C, 80% RH (non-condensing) (charging temperature range: 5°C to 35°C)		
Storage temperature and humidity range	-20°C to 60°C, 80% RH (non-condensing)		
Vibration resistance	JIS D 1601:1995 5.3 (1), Class 1A (passenger vehicle) equivalent		
LED display - infos@distrame.fr	Wireless connection and measurement status, error status, AC		

Auto-connect function	Available
Accessories	Z3230 WIRELESS LAN ADAPTER, user manual, Z1008 AC ADAPTER, mounting plate, M3×4 screw × 2 (for use with mounting plate), wiring confirmation label (LR8534 only)
Z3230 wireless specifications	Wireless LAN (IEEE 802.11b/g/n) Range: 30 m (line of sight) Encryption: WPA-PSK/WPA2-PSK, TKIP/AES Channels: channel 1 to 11

Power supply specifications			
AC adapter	Z1008 AC ADAPTER (12 V DC, standard accessory) Rated supply voltage: 100 to 240 V AC Rated power supply frequency: 50/60 Hz Maximum rated power: 25 VA (including AC adapter) Normal power consumption (instrument only, without battery pack) LR8530, LR8532, LR8533: 2.5 VA LR8531; 3.0 VA LR8534, LR8535: 4.0 VA		
Battery	Z1007 BATTERY PACK (when using AC adapter, AC adapter takes precedence.) Rated supply voltage: 7.2 V DC (Li-ion 2170 mAh) Maximum rated power LR8530, LR8532: 1.5 VA LR8531, LR8533: 2.0 VA LR8534, LR8535: 3.5 VA		
External power supply	Rated supply voltage: 10 to 30 V DC Maximum rated power: 8 VA (30 V DC external power supply, while charging battery) Normal power consumption (12 V DC external power supply, without battery pack) LR8530, LR8532, LR8533: 2.5 VA LR8531: 3.0 VA LR8534, LR8535: 4.0 VA		
Continuous operating time	When using Z1007 BATTERY PACK (all data refresh rates, good communications state, 23°C reference values) LR8530, LR8532, LR8533: approx. 9 h LR8531: approx. 7 h LR8534: approx. 5 h LR8535: approx. 10 h (approx. 5 h when using two non-contact CAN sensors)		
Charging function	When Z1007 BATTERY PACK installed while connected to AC adapter or 10 to 30 V DC external power supply Charging time: approx. 7 h (23°C reference value)		

VOLTAGE/TEMP UNIT U8550 UNIVERSAL UNIT U8551 VOLTAGE/TEMP UNIT U8552

(Accuracy guaranteed for 1 year)

General specifications

Accessories

General specificati	ons
Number of input channels	U8550: 15 (set voltage, thermocouple, or humidity for each channel) LR8530: 15 (set voltage or thermocouple for each channel) U8551, LR8531: 15 (set voltage, thermocouple, humidity, RTD, or resistor for each channel) U8552: 30 (set voltage, thermocouple, or humidity for each channel) LR8532: 30 (set voltage or thermocouple for each channel)
Input terminals	U8550, LR8530: M3 screw-type terminal block (2 terminals per channel) U8551, LR8531: push-button type terminal block (4 terminals per channel) U8552, LR8532: push-button type terminal block (2 terminals per channel)
Output terminals	M3 screw-type terminal block (1 output, 2 terminals, Z2000 HUMIDITY SENSOR power supply [can power up to 15 Z2000 HUMIDITY SENSOR])(LR8531 only)
Measurement target	U8550, U8552: voltage, temperature (thermocouples), humidity LR8530, LR8532: voltage, temperature (thermocouples) U8551, LR8531: voltage, temperature (thermocouples), humidity, temperature (RTD), resistor
Input type	Scanning by semiconductor relays All channels isolated (not isolated when measuring with RTD, resistance or humidity)
A/D resolution	16 bits
Maximum input voltage	±100 V DC (maximum voltage between input terminals without causing damage)
Maximum channel- to-channel voltage	300 V DC (maximum voltage that can be applied between each input channel without causing damage; not isolated when measuring with RTD, resistance or humidity) *Channels are isolated from each other with semiconductor relays. Never allow a voltage exceeding the product specifications, for example a lightning surge, to be applied across channels as doing so may cause the semiconductor relays to short.
Maximum rated terminal-to-ground voltage	300 V AC, DC (maximum voltage that can be applied between input channels and the instrument or its chassis, or between units without causing damage; humidity measurement not isolated)
Input resistance	$10~M\Omega$ or greater (10 mV f.s. to 2 V f.s. voltage ranges, thermocouple ranges, RTD and resistor ranges) $1~M\Omega$ ±5% (10 V f.s. to 100 V f.s. voltage range, 1-5 V f.s. voltage range, humidity measurement)
Allowable signal source resistance	1 kΩ or less
Data refresh interval	10 ms to 10 s (10 selectable levels)
Digital filters	Digital filter cutoff frequency is automatically set to data refresh interval, burnout setting, and power supply frequency filter setting
Dimensions	U8550, U8551, U8552: approx. 134W × 70H × 63D mm (5.28"W × 2.76"H × 2.48"D) LR8530, LR8531, LR8532: approx. 154W × 106H × 57D mm (6.06"W × 4.17"H × 2.24"D)
Mass	U8550: approx. 345 g (12.2 oz.), U8551: approx. 318 g (11.2 oz.), U8552: approx. 319 g (11.3 oz.), LR8530: approx. 423 g (14.9 oz.), LR8531: approx. 386 g (13.6 oz.), LR8532: approx. 388 g (13.7 oz.), (including Z3230 WIRELESS LAN ADAPTER)

Analog input specifications (23 \pm 5°C [73 \pm 9°F], 80% rh or less, after 30 minutes of warm-up and zero-adjustment, with the 50/60 Hz cut-off setting selected)

Voltage

Range	Maximum resolution	Measurable range	Measurement accuracy
10 mV f.s.	500 nV	-10 mV to 10 mV	±10 μV
20 mV f.s.	1 μV	-20 mV to 20 mV	±20 μV
100 mV f.s.	5 μV	-100 mV to 100 mV	±50 μV
200 mV f.s.	10 μV	-200 mV to 200 mV	±100 μV
1 V f.s.	50 μV	-1 V to 1 V	±500 μV
2 V f.s.	100 μV	-2 V to 2 V	±1 mV
10 V f.s.	500 μV	-10 V to 10 V	±5 mV
20 V f.s.	1 mV	-20 V to 20 V	±10 mV
100 V f.s.	5 mV	-100 V to 100 V	±50 mV
1-5 V f.s.	500 μV	1 V to 5 V	±5 mV

Temperature

Thermocouple (not including accuracy of reference junction compensation) Standards: JIS C1602-2015 IFC584

ype		Measurable range	Maximum resolution	Measurement accura
K	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
			0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
			0°C to 500°C	±0.5
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
			0°C to less than 500°C	±0.5
			500°C to 1,350°C	±0.7
J	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
			0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±0.9
			-100°C to less than 0°C	±0.7
			0°C to 500°C	±0.5
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±0.9
			-100°C to less than 0°C	±0.7
			0°C to 1,200°C	±0.5
Е	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
			0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±0.9
			-100°C to less than 0°C	±0.7
			0°C to 500°C	±0.5
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±0.9
	_,000 0	0 0	-100°C to less than 0°C	±0.7
		-	0°C to 1,000°C	±0.5
Т	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
	100 0 1.3.	0.010	0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±1.4
	300 0 1.3.	0.03 0	-100°C to less than 0°C	±0.7
		-	0°C to 400°C	±0.5
	2000°C f.s.	0.1°C	-200°C to less than -100°C	±1.4
	2000 C 1.5.	0.10	-100°C to less than 0°C	±0.7
			0°C to 400°C	
N	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.5
IN	100 € 1.5.	0.01 C		±1.1
	500°C f a	0.05°C	0°C to 100°C	±0.9
	500°C f.s.	0.05°C	-200°C to less than -100°C -100°C to less than 0°C	±2.1
		-		±1.1
	0.00000.6	0.400	0°C to 500°C	±0.9
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±2.1
			-100°C to less than 0°C	±1.1
_	40000 /	2 2 4 2 2	0°C to 1,300°C	±0.9
R	100°C f.s.	0.01°C	0°C to 100°C	±4.4
	500°C f.s.	0.05°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 500°C	±2.2
	2000°C f.s.	0.1°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 1,700°C	±2.2
S	100°C f.s.	0.01°C	0°C to 100°C	±4.4
	500°C f.s.	0.05°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 500°C	±2.2
	2,000°C f.s.	0.1°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 1,700°C	±2.2
В	2,000°C f.s.	0.1°C	400°C to less than 600°C	±5.4
			600°C to less than 1,000°C	±3.7
			1,000°C to 1,800°C	±2.4
С	100°C f.s.	0.01°C	0°C to 100°C	±1.7
	500°C f.s.	0.05°C	0°C to 500°C	±1.7
				±1.7

Reference junction compensation: internal/external	At INT RJC, total accuracy = add ±0.5°C
detection: on/off	System will check for burnout at each data refresh interval during thermocouple measurement. (not available with 10 ms interval)

U8550, U8551, U8552, LR8531 only input specifications **Humidity** (use HUMIDITY SENSOR Z2000)

HUMIDITY SENSOR Z2000

Operating temperature and humidity range:

0°C to 50°C (32°F to 122°F), 100% RH or less (non-condensing)


Range	Maximum resolution	Measurable range
100% rh f.s.	0.1% rh	5.0% rh to 95.0% rh

HUMIDITY SENSOR Z2000 accuracy

If the humidity value lies on a boundary line below, the better of the two regions' mea-

surement accuracy values applies.





U8551, LR8531 only input specifications

Temperature RTD

Connection: 3-wire/4-wire, measurement current: 1mA (Pt100, Jpt100), 0.1mA (Pt1000) Standards: Pt100, Pt1000: JIS C1604-2013, IEC751 JPt100: JIS C1604-1989

Type	Range	Maximum resolution	Measurable range	Measurement accuracy
	100°C f.s.	0.01°C	-100°C to 100°C	±0.5°C
Pt100	500°C f.s.	0.05°C	-200°C to 500°C	±0.7°C
	2,000°C f.s.	0.1°C	-200°C to 800°C	±0.9°C
	100°C f.s.	0.01°C	-100°C to 100°C	±0.5°C
JPt100	500°C f.s.	0.05°C	-200°C to 500°C	±0.7°C
	2,000°C f.s.	0.1°C	-200°C to 500°C	±0.9°C
	100°C f.s.	0.01°C	-100°C to 100°C	±0.5°C
Pt1000	500°C f.s.	0.05°C	-200°C to 500°C	±0.7°C
	2,000°C f.s.	0.1°C	-200°C to 800°C	±0.9°C

^{*}When using Pt1000, data refresh intervals of 10ms, 20m, and 50ms are not available.

Resistance
Connection: 4-wire; measurement current is 1 mA

Range	Maximum resolution	Measurable range	Measurement accuracy
10 Ω f.s.	0.5 mΩ	0 Ω to 10 Ω	±10 mΩ
20 Ω f.s.	1 mΩ	0 Ω to 20 Ω	±20 mΩ
100 Ω f.s.	5 mΩ	0 Ω to 100 Ω	±100 mΩ
200 Ω f.s.	10 mΩ	0 Ω to 200 Ω	±200 mΩ

WIRELESS HIGH SPEED VOLTAGE UNIT LR8531

(Accuracy guaranteed for 1 year)

General specifications

Number of input channels	5 (voltage only)
Input terminals	M3 screw-type terminal block (2 terminals per channel), outfitted with terminal block cover
Measurement target	Voltage
Input type	Scanning by semiconductor relays, all channels isolated
A/D resolution	16 bits
Maximum input voltage	±100 V DC (maximum voltage between input terminals without causing damage)
Maximum channel-to- channel voltage	300 V DC (maximum voltage between input channels without causing damage)
	*Channels are isolated from each other with semiconductor relays. Never allow a voltage exceeding the product specifications, for example a lightning surge, to be applied across channels as doing so may cause the semiconductor relays to short.
Maximum rated termi- nal-to-ground voltage	300 V AC, DC (maximum voltage between input channel and chassis, or between modules, without causing damage)
Input resistance	1 MΩ ±5%
Allowable signal source resistance	100 Ω or less
Data refresh interval	1 ms to 10 s (13 selectable levels)
Digital filters	Digital filter cutoff frequency is automatically set to data refresh interval, burnout detection setting, and power supply frequency filter setting.
Dimensions	U8553: approx. 134W×70H×63D mm (5.28"W×2.76"H×2.48"D) LR8531: approx. 154W×106H×57D mm (6.06"W×4.17"H×2.24"D)
Mass	U8553: approx. 237 g (8.4 oz.) LR8531: approx. 370 g (13.1 oz.) (including Z3230 WIRELESS LAN

Analog input specifications (23 \pm 5°C/73 \pm 9°F, 80% rh or less, after 30 minutes of warm-up and zero-adjustment, with the 50/60 Hz cut-off setting selected)

Measurement target	Range	Maximum resolution	Measurable range	Measurement accuracy
Voltage	100 mV f.s.	5 μV	-100 mV to 100 mV	±100 μV
	200 mV f.s.	10 μV	-200 mV to 200 mV	±200 μV
	1 V f.s.	50 μV	-1 V to 1 V	±1 mV
	2 V f.s.	100 μV	-2 V to 2 V	±2 mV
	10 V f.s.	500 μV	-10 V to 10 V	±10 mV
	20 V f.s.	1 mV	-20 V to 20 V	±20 mV
	100 V f.s.	5 mV	-100 V to 100 V	±100 mV
	1-5 V f.s.	500 μV	1 V to 5 V	±10 mV

STRAIN UNIT U	J8554	WIRELESS STRAIN UNIT LR8534		
(Accuracy guarant		year)		
General specifica				
Number of input channels	5 (set vo	Itage or strain for each channel)		
Input terminals	Push-but terminal l	Push-button type terminal block (5 terminals per channel), outfitted with terminal block cover, set DIP switches according to measurement target		
Measurement	Voltage			
target	Strain	Strain gage-type converter Strain gage 1-gage method (2-wire setup), 1-gage method (3-wire setup), 2-gage method (adjacent sides), 4-gage method		
Adaptive gage resistance		nethod, 2-gage method: 120 Ω (external bridge box required for 350 Ω nethod: 120 Ω to 1 $k\Omega$		
Gage ratio	2.0 (fixed	d)		
Bridge voltage	2 V ±0.0	5 V DC		
Balance	Method	Electronic auto-balancing		
adjustment	Range	Voltage: ± 20 mV or less (1 mV f.s. to 20 mV f.s. range), ± 200 mV or less (50 mV f.s. to 200 mV f.s. range) Strain: $\pm 20,000$ με or less (1,000 με f.s. to 20,000 με f.s. range), $\pm 200,000$ με or less (50,000 με f.s. to 200,000 με f.s. range)		
Input type		d differential input, simultaneous sampling of all channels (non- channels)		
A/D resolution	16bit			
Maximum input voltage	±0.5 V D damage)	C (maximum voltage between input terminals without causing		
Maximum channel- to-channel voltage	Non-isola	ated (all channels share common GND)		
Maximum rated terminal-to-ground voltage				
Input resistance	2 MΩ ±5	%		
Data refresh interval	1 ms to 1	0 s (13 selectable levels)		
Low-pass filter	Cut-off frequency: -3 dB ±30% Auto, 120, 60, 30, 15, 8, 4 (Hz) Auto: cut-off frequency of low-pass filter is automatically set based on set data refresh interval.			
	Attenuati	on characteristics: 5th-order butterworth filter, −30 dB/oct		
Dimensions	U8554: ap LR8534: a	prox. 134W×70H×63Dmm (5.28"W×2.76"H×2.48"D) pprox. 154W×106H×57D mm (6.06"W×4.17"H×2.24"D)		
Mass	s U8554: approx. 236 g (8.3 oz.) LR8534: approx. 372 g (13.1 oz.) (including Z3230 WIRELESS LAN ADAPTER			

Analog input specifications (23 ± 5 C/73 ± 9 F, 80% rh or less, auto-balance at least 30 minutes after power on, with LPF set at 4 Hz)

Measure- ment target	Range	Maximum resolution	Measurable range	Measurement accuracy
Voltage	1 mV f.s.	50 nV	-1 mV to 1 mV	±9 μV
	2 mV f.s.	100 nV	-2 mV to 2 mV	±10 μV
	5 mV f.s.	250 nV	-5 mV to 5 mV	±25 μV
	10 mV f.s.	500 nV	-10 mV to 10 mV	±50 μV
	20 mV f.s.	1 μV	-20 mV to 20 mV	±100 μV
	50 mV f.s.	2.5 µV	-50 mV to 50 mV	±250 μV
	100 mV f.s.	5 μV	-100 mV to 100 mV	±500 μV
	200 mV f.s.	10 μV	-200 mV to 200 mV	±1 mV
Strain	1,000 με f.s.	0.05 με	-1,000 με to 1,000 με	±9 με
	2,000 με f.s.	0.1 με	-2,000 με to 2,000 με	±10 με
	5,000 με f.s.	0.25 με	-5,000 με to 5,000 με	±25 με
	10,000 με f.s.	0.5 με	-10,000 με to 10,000 με	±50 με
	20,000 με f.s.	1 με	-20,000 με to 20,000 με	±100 με
	50,000 με f.s.	2.5 με	-50,000 με to 50,000 με	±250 με
	100,000 με f.s.	5 με	-100,000 με to 100,000 με	±500 με
	200,000 με f.s.	10 με	-200,000 με to 200,000 με	±1000 με

^{*} Internal bridge resistance precision tolerance: ±0.01%; temperature characteristics: ±2 ppm/°C * Measurement accuracy does not include internal bridge resistance tolerance and temperature characteristics

CAN UNIT U8555 WIRELESS CAN UNIT LR8535

General specifications

Number of ports 2 D-sub 9 pin MALE × 2 Input terminals

	_	
Pin No.	Signal	Function
1	N.C.	Unused
2	CAN_L	CAN_L communications line
3	GND	GND
4	N.C.	Unused
5	N.C.	Unused
6	N.C.	Unused
7	CAN_H	CAN_H communications line
8	N.C.	Unused
9	N.C.	Unused

		9	N.C.	Unused		
Power supply terminals (LR8535 only)	USB Dedi	port (connectated power	ctors: Series supply for H	A receptacle × 2) ioki NON-CONTACT CAN SENSO	R	
Interface	CAN	, CAN FD, C	AN FD (non	-ISO)		
Terminator		Dn/off setting available for each port 120 Ω ±10 Ω built-in resistance				
ACT LED	Displ	ays CAN bu	s operating s	status		
TERM LED	Illum	inates when	terminator is	on		
Data refresh interval	10 m	10 ms to 10 s (10 selectable levels)				
Baud rate	500k	, 800k, 1,Ò00	Ok [Baud]	k, 62.5k, 83.3k, 100k, 125k, 250k, 1, 2.5M, 4M, 5M [Baud]		
Sampling point		or CAN FD FD (data): 5		50.0% to 95.0% 0%		
ACK transmission	ACK	response wi	nen receivin	g CAN data can be set to on or off		
Operation mode	value	55: supports e output mod 535: supports	e	tween receive mode and measured e mode	d	
Dimensions				4D mm (5.28"W×2.76"H×2.13"D) ×48D mm (6.06"W×4.17"H×1.89"D)		
Mass		3: approx. 23 31: approx. 35		ncluding Z3230 WIRELESS LAN ADAPT	ER)	

Receive mode specifications

No. of measurement channels	Data refresh interval 10 ms: max. 50 channels (max. 50 signals) Data refresh interval 20 ms: max. 100 channels (max. 100 signals) Data refresh interval 50 ms: max. 250 channels (max. 250 signals) Data refresh interval 100 ms or greater: max. 500 channels (max. 500 signals)
Receive ID count	Function for recording the number of times a target ID is received during the data refresh interval
User-defined frame transmission (U8555 only)	Sends user-defined CAN frames during receive mode operation No. of configurable conditions: 8 per unit
Massurad values	s output mode specifications (U8555 only)

Overview	Converts LR8450 measured values and output them as CAN frames.
Output target	Measurement data from plug-in modules (other than CAN Unit)
Output data refresh period	Depends on data refresh interval of module generating output (as fast as 1 ms)
Response	Data refresh interval × 2 + 1 ms + analog response time (*1) 1 Varies with filter settings (U8554: 5 ms with 120 Hz low-pass filter)

	Function specifications (LR8535 only)		
		Wireless connection, measurement status, error status, AC adapter or external power supply, battery power, charge status	
	Control keys	[AUTO], [RESET]	
	Auto-connect function	Available	

CAN Editor (software) specifications

General	specification	15
General	Specification	ıo

General specificati	ons			
Operating environment	Windows 10 (32/64-	-bit), Windows 11 (64-bit)		
Interface	LAN/USB			
Supported languages	Japanese/English/C	Chinese		
Supported instruments	HIOKI LR8450/LR84	450-01 MEMORY HILOGGER		
Set module position				
CAN interface set- ting	Interface, terminator, baud rate, data rate, sampling points, data sampling points, ACK			
Module operating mode	Switch between receive mode and measured value output mode on a module-by-module basis			
Receive mode sett	ings			
Data refresh interval	10 ms to 10 s (10 selectable levels)			
Receive channel	CAN input port settings	Port 1 or Port 2		
definition settings	Channel type	Data or ID count		
	Shared settings	1. Format: standard/extended 2. ID: 0h to 1 FFFFFFh 3. Comment 4. Unit 5. Factor, offset		
	Channel type: data	1. Start bits: 0 to 511 2. Bit length: 1 to 64 [bits] 3. Byte order: Motorola/Intel 4. Data type: unsigned/signed/IEEE/float/IEEE-double		
	LR8450 display settings	Display upper limit value or display lower limit value No. of display digits, display format Numerical calculation threshold Waveform color		
User-defined frame transmission set-	Receive condition numbe	No. 1 to No. 8		
tings	CAN output port set- ting	Port 1 or Port 2		
	No. of frame	1 to 8		
	Regular transmis- sion setting	On/off		
	Regular transmis- sion interva	1 to 9999 (× 10 [ms])		
	Timing	At measurement start, at measurement stop, at start trigger, at alarm, manual		
	Frame type	CAN standard, CAN extended, CAN FD standard, CAN FD extended		
	Transmit ID	0 h to 1FFFFFFF h		
	DLC (bite)	0 to 15 (0, 12, 16, 20, 24, 32, 48, 64)		
	Transmit data	Set as hexadecimal value		
	Delay	0 to 9999 (× 10 [ms])		
Measured value out	put mode setting			
Measured value output setting	CAN output port setting	Port 1 or Port 2		
	Frame type	Standard/extended		
	ID	0 h to 1FFFFFFF h		
	Data	Measured values from the following modules can be set as output data		
CAN bus load ratio estimation function		U8550, U8551, U8552, U8553, U8554 Id be the CAN bus load increase rate if		
File specifications	ications			
Save function				
Load function	Loads CANdb files (.dbc) and MR8904 definition files (.CDF) and use them to configure receive channel settings. Loads LR8450 settings (.SET) and CAN Editor settings (.CES) and applies them to the CAN Editor's overall settings.			
	Sets titles for settings data (.CES) (up to 50 single-byte or 25 double-byte characters).			

Model: MEMORY HILOGGER LR8450



Option

Plug-in modules



VOLTAGE/TEMP UNIT U8550

Channels: 15: maximum sampling rate: 10 ms



UNIVERSAL UNIT U8551 Channels: 15; maximum sampling rate: 10 ms

VOLTAGE/TEMP UNIT U8552



Channels: 30: maximum sampling rate: 20 ms

(When 15 or fewer channels are used, 10 ms)



HIGH SPEED VOLTAGE UNIT U8553

Channels: 5; maximum sampling rate: 1 ms



STRAIN UNIT U8554

Channels: 5; maximum sampling rate: 1 ms



CAN UNIT U8555

Ports: 2, input: CAN or CAN FD, output: CAN or CAN FD maximum sampling rate: 10 $\ensuremath{\mathsf{ms}}$

Model No. Specifications (order code) LR8450 Standard model, main unit only LR8450-01 Wireless LAN equipped model, main unit only

- The LR8450 and LR8450-01 cannot perform measurement on their own. One or more plug-in modules or wireless modules are required (sold separately).
- The LR8450-01 and each wireless module emit radio waves. Use of radio waves is subject to licensing requirements in certain countries. Using it in a country or region other than those indicated may violate the law and may result in legal penalties for the operator. For the latest information about countries and regions where wireless operation is currently supported, please visit the Hioki website.

Wireless modules



WIRELESS VOLTAGE/TEMP UNIT LR8530

Channels: 15: maximum sampling rate: 10 ms



WIRELESS UNIVERSAL UNIT LR8531

Channels: 15; maximum sampling rate: 10 ms



WIRELESS VOLTAGE/TEMP UNIT LR8532

Channels: 30: maximum sampling rate: 20 ms (When 15 or fewer channels are used, 10 ms)



WIRELESS HIGH SPEED VOLTAGE UNIT LR8533

Channels: 5; maximum sampling rate: 1 ms



WIRELESS STRAIN UNIT LR8534

Channels: 5; maximum sampling rate: 1 ms



WIRELESS CAN UNIT LR8535

Ports: 2, input: CAN or CAN FD, maximum sampling rate: 10 ms

Power supplies

For instrument and wireless modules



BATTERY PACK Z1007

Instrument takes two wireless modules take one For instrument



AC ADAPTER Z1014

For wireless modules



AC ADAPTER Z1008

Fixed Stand



FIXED STAND Z5040

For installing logger on wall

CASE



CARRYING CASE C1012

Accommodates instrument and four plug-in modules or seven wireless modules

Wireless Lan Adapter

For wireless modules



WIRELESS LAN ADAPTER Z3230

Cables, sensors, etc.



LAN CABLE 9642

Straight Ethernet cable, supplied with straight to cross conversion adapter, 5 m (16.41 ft) length



HUMIDITY SENSOR Z2000

(analog output), 3 m (9.84 ft) length



Thermocouple

For reference only. Please purchase locally.



CAN CABLE 9713-01

For the U8555, LR8535. Unprocessed on one end, 1.8 m (5.91 ft) length



NON-CONTACT CAN SENSOR SP7001-95

Supports CAN FD or CAN signals, SP7001, SP9250, SP7150 set

Storage media

*Always use HIOKI optional storage media. Proper operation is not guaranteed when using storage media from other manufacturers, and may prevent the product from saving and loading data properly.



SD memory card Z4001

2 GB capacity



SD memory card Z4003

8 GB capacity



USB drive Z4006

16 GB, long-life, high-reliability SLC flash memory

For the PC





LOGGER UTILITY/CAN EDITOR

LOGGER UTILITY: The control of the measurement of loggers, real-time data collection CAN EDITOR: CAN configuration software Standard accessory

GENNECT One Displays measurement results from multiple instruments in graph form

Free application for Windows

You can download the latest version from our website

Note: Company names and product names appearing in this catalog are trademarks or registered trademarks of various companies.



DISTRIBUTED BY

DISTRAME

Parc du Grand Troyes - Quartier Europe Centrale, 40 rue de Vienne - 10300 SAINTE-SAVINE Tél.: 03 25 71 25 83 - infos@distrame.fr - www.distrame.fr

